

Table of Contents

Introduction	2
Input database	2
Time-independent "client files"	2
Time-dependent files	3
Species split/speciation	3
Geographic references	3
Modules reference	3
Modules glossary	3
General modules	3
Model-specific modules	4
Example batch files to run EMGR modules	4
EMMA shell commands	4
System description and architecture	4
Shell commands reference	4
Appendix - Other files formats	5

Welcome to Emission Manager users' guide


Modular processing system for model-ready emission input preparation

This guide is organized in the following sections:

- [Introduction](#): gives an overview of Emission Manager architecture and working mode
- [Input database](#): describes the formats of all input files constituting the Emission Manager input database for a given application
- [Modules reference](#): description of all the individual computational modules (purpose & functions, input/output, calling syntax)
- [EMMA shell commands](#): set of preset shell commands and procedures helping the automated creation of emission input for air quality models through a coordinated use of Emission Manager

Other files formats are illustrated in the [Appendix](#).

[Alphabetical index of manual pages](#).



[Introduction](#)

- [Foreword](#)
- [Use of Emission Manager modules](#)
- [Changes from previous versions](#)

Input database

- [Introduction](#)
- [Reference classification scheme](#)

[Time-independent “client files”](#)

- [Common features and conventions](#)
- [Point sources client file \(GSP\)](#)
- [Line sources client file \(LIN\)](#)
 - [simplified file](#)
 - [complex file](#)

Area sources client file (SRF)

- [simplified file](#)
- [complex file](#)

Time-dependent filesModulation files

- [Yearly modulation profiles file](#)
- [Weekly modulation profiles file](#)
- [Daily modulation profiles file](#)
- [Sources-specific modulation profiles mapping file](#)
- [Categories-based modulation profiles mapping file](#)

Files for time-varying modification of sources emissions

- [Time-varying modification factors file](#)
- [Sources-specific modification factors mapping file](#)
- [Categories-based modification factors mapping file](#)

Hour-by-hour modulation files

- [Hour-by-hour modulation profiles file](#)
- [Sources-specific hour-by-hour modulation profiles mapping file](#)
- [Categories-based hour-by-hour modulation profiles mapping file](#)
- [Parameters file for temperature-dependent modulation, by climatic zone](#)
- [Time-dependent client files](#)
- [Continuous emission monitoring systems \(CEMS\) files](#)

Species split/speciation

- [Splitting profiles database](#)
- [Categories-based split profiles mapping file](#)
- [Sources-specific split profiles mapping file](#)

Geographic references

- [Vector cartography file \(DONCAR\)](#)
- [Polygons-to-grid intersections file](#)
- [Gridded thematic data \(LDU\)](#)
- [Categories - thematic layers mapping file \(SNAP-CRS\)](#)

Modules reference**Modules glossary****General modules**

- Generation of "pemtim" files from time-independent "client files"
 - [TRLGSP](#)
 - [TRLLIN](#)
 - [TRLCRS](#)
- Generation of "pemtim" files from time series of data
 - [INEMOS](#)
- Dealing with species
 - [SPICE](#)
 - [REDSPE](#)
- Dealing with time
 - [CRTEMP](#)
 - [CATPER](#)
 - [MODGRID](#)

- Grid allocation
 - [LIGREC](#)
 - [PEM2GRID](#)
 - [MODGRID](#)
 - [BINRAS](#)
- Other modules
 - [ALTEMI](#)
 - [CATSOU](#)
 - [PEMSOM](#)
 - [BILSOU](#)
 - [PEMMOD](#)
 - [POLMOD](#)
 - [PEM2MIF](#)
 - [PEMSTAT](#)
- Pre-processing modules
 - [FCSPLIT](#)
 - [MIF2LIN](#)

Model-specific modules

- [ARQRAS/ARQRASLITE](#)
- [CALEMIS](#)
- [BOTTARGA](#)
- [MPEM2FARM](#)

Example batch files to run EMGR modules

EMMA shell commands

System description and architecture

Introduction

- [Changes from previous versions](#)
- [Installation](#)
- [System configuration: emma_config.mak](#)

"Case" structure

- [Input files and directories structure](#)
- [Subcases and networks](#)

Configuration files

- ["Case" configuration: case.mak](#)
- ["Subcase" configuration: subcase.mak](#)
- ["Network" configuration: network.mak](#)

Calculations workflows

- [SPRAY](#)
- [FARM](#)
- [Logfiles and error tracking](#)

Shell commands reference

Top-level commands

- [SPRAY_emi](#)
- [FARM_emi](#)
- [FARM_lump_profiles](#)
- [TREFIC_FARM_emi](#)

Low-level commands

- [SPRAY_point_sources](#)
 - [SPRAY_ems_sources](#)
 - [SPRAY_line_sources](#)
 - [SPRAY_area_sources](#)
 - [FARM_point_sources](#)
 - [FARM_ems_sources](#)
 - [FARM_line_sources](#)
 - [FARM_area_sources](#)
- [Utility commands](#)
- [touch_case_FARM](#)
 - [copy_case](#)

Appendix - Other files formats

- [PENTIM](#)
- [PEMSPE](#)
- [Simple stacks default parameters file](#) (gspdef.txt)
- [Stacks default parameters file](#) (gspdef.txt)
- [INEMOS initialization file](#)
- [Emissions modification factors file \(POLMOD\)](#)
- [Emissions alterations file](#)